


Step By Step Guide - Mechanical Pencil Sharpener Maintenance 1 - How to remove the blade mechanism for inspection

STEP 1

Twist the black locking-ring a quarter-turn anti-clockwise.



STEP 2



STEP 3

