

Step By Step Guide - Mains Operated Sharpeners

STEP 1

Place the sharpener on a flat surface. Connect the electricity plug to any standard power socket.



STEP 2

If you have the Swordfish 40051 Pencil Point Options sharpener, then check that the desired pencil point is selected using the dial on top of the sharpener.



STEP 3

Insert the pencil, holding it firmly and pressing lightly.



STEP 4

The sharpener will automatically stop sharpening when the pencil has reached the selected sharpness. When this occurs remove the pencil.



STEP 5

Empty the shavings tray if necessary by sliding it out from the main sharpener unit. It is recommended that you clean the blade regularly with a small brush.

